



F1	F2	F3	F4	F5	F6
!	@	#	\$	%	^
1	2	3	4	5	6
~ ,	Q q	W w	E e	R r	T t
K45	A a	S s	D d	F f	G g
↑	Z z	X x	C c	V v	B b
	Ctrl	Alt	- _		

Esc	Num Lock	7 ↖	8 ↑	9 ↗	/	▲
Caps Lock	=	4 ←	5	6 →	*	◀▶
Prt Sc	Scr Lk	1 ↙	2 ↓	3 ↘	-	◀▶
Pause	Ins	0 Ins	. Del	Enter ↵	+	⊞

F7	F8	F9	F10	F11	F12
&	*	()	{	}
7	8	9	0	[]
Y y	U u	I i	O o	P p	 \
H h	J j	K k	L l	:	"
N n	M m	<	>	?	↑
;	w	, k	. -	/ x	
+	Alt Gr	⌂	Ctrl		

Maltron Qwerty Caps Num Scroll



Win/PC
English US

L90 Qwerty Maltron